

Wireless Networks

Lecture 26: LTE

Peter Steenkiste
CS and ECE, Carnegie Mellon University
Peking University, Summer 2016

Overview

- **Motivation**
- **Architecture**
- **Resource management**
- **LTE protocols**
- **Radio access network**
 - » OFDM refresher
- **LTE advanced**

Some slides based on material from
“Wireless Communication Networks and Systems”
© 2016 Pearson Higher Education, Inc.

Purpose, motivation, and approach to 4G

- Defined by ITU directives for International Mobile Telecommunications Advanced (IMT-Advanced)
- All-IP packet switched network.
- Ultra-mobile broadband access
- Peak data rates
 - » Up to 100 Mbps for high-mobility mobile access
 - » Up to 1 Gbps for low-mobility access
- Dynamically share and use network resources
- Smooth handovers across heterogeneous networks
 - » 2G and 3G networks, small cells such as picocells, femtocells, and relays, and WLANs
- High quality of service for multimedia applications

Peter A. Steenkiste, CMU

3

High Level Features

- No support for circuit-switched voice
 - » Instead providing Voice over LTE (VoLTE)
- Replace spread spectrum/CDMA with OFDM


Technology	1G	2G	2.5G	3G	4G
Design began	1970	1980	1985	1990	2000
Implementation	1984	1991	1999	2002	2012
Services	Analog voice	Digital voice	Higher capacity packetized data	Higher capacity, broadband	Completely IP based
Data rate	1.9. kbps	14.4 kbps	384 kbps	2 Mbps	200 Mbps
Multiplexing	FDMA	TDMA, CDMA	TDMA, CDMA	CDMA	OFDMA, SC-FDMA
Core network	PSTN	PSTN	PSTN, packet network	Packet network	IP backbone

Peter A. Stee

4

LTE Architecture

- **evolved NodeB (eNodeB)**
 - » Most devices connect into the network through the eNodeB
- **Evolution of the previous 3GPP NodeB (~2G BTS)**
 - » Uses OFDM instead of CDMA
- **Has its own control functionality**
 - » Dropped the Radio Network Controller (RNC - ~2G BSC)
 - » eNodeB supports radio resource control, admission control, and mobility management (handover)
 - » Was originally the responsibility of the RNC



Peter A. Steenkiste, CMU

5

Evolved Packet System

- **Overall architecture is called the Evolved Packet System (EPS)**
- **3GPP standards divide the network into**
- **Radio access network (RAN): cell towers and connectives to mobile devices**
- **Core network (CN): management and connectivity to other networks**
- **Each can evolve independently**
 - » Driven by different technologies: optimizing spectrum use versus management and control or traffic

Peter A. Steenkiste, CMU

6

Evolved Packet System Components

- **Long Term Evolution (LTE) is the RAN**
 - » Called Evolved UMTS Terrestrial Radio Access (E-UTRA)
 - » Enhancement of 3GPP's 3G RAN
 - » eNodeB is the only logical node in the E-UTRAN
 - » No RNC
- **Evolved Packet Core (EPC)**
 - » Operator or carrier core network –core of the system
- **Traditionally circuit switched but now entirely packet switched**
 - » Based on IP - Voice supported using voice over IP (VoIP)

Design Principles of the EPS

- **Packet-switched transport for traffic belonging to all QoS classes**
 - » Voice, streaming, real-time, non-real-time, background
- **Comprehensive radio resource management**
 - » End-to-end QoS, transport for higher layers
 - » Load sharing/balancing
 - » Policy management across different radio access technologies
- **Integration with existing 3GPP 2G and 3G networks**
- **Scalable bandwidth from 1.4 MHz to 20 MHz**
- **Carrier aggregation for overall bandwidths up to 100 MHz**

Evolved Packet Core Components

- **Mobility Management Entity (MME)**
 - » Supports user equipment context, identity, authentication, and authorization
- **Serving Gateway (SGW)**
 - » Receives and sends packets between the eNodeB and the core network
- **Packet Data Network Gateway (PGW)**
 - » Connects the EPC with external networks
- **Home Subscriber Server (HSS)**
 - » Database of user-related and subscriber-related information
- **Interfaces**
 - » S1 interface between the E-UTRAN and the EPC
 - For both control purposes and for user plane data traffic
 - » X2 interface for eNodeBs to interact with each other
 - Again for both control purposes and for user plane data traffic

Overview

- **Motivation**
- **Architecture**
- **Resource management**
- **LTE protocols**
- **Radio access network**
 - » OFDM refresher
- **LTE advanced**

Some slides based on material from
“Wireless Communication Networks and Systems”
© 2016 Pearson Higher Education, Inc.

LTE Resource Management

- LTE uses *bearers* for quality of service (QoS) control instead of circuits
- EPS bearers
 - » Between PGW and UE
 - » Maps to specific QoS parameters such as data rate, delay, and packet error rate
- Service Data Flows (SDFs) differentiate traffic flowing between applications on a client and a service
 - » SDFs must be mapped to EPS bearers for QoS treatment
 - » SDFs allow traffic types to be given different treatment
- End-to-end service is not completely controlled by LTE

Bearer Management based on QoS Class Identifier

QCI	Resource Type	Priority	Packet Delay Budget	Packet Error Loss Rate	Example Services
1	GBR	2	100 ms	10^{-2}	Conversational Voice
2		4	150 ms	10^{-3}	Conversational Video (live streaming)
3		3	50 ms	10^{-3}	Real Time Gaming
4		5	300 ms	10^{-6}	Non-Conversational Video (buffered streaming)
5		1	100 ms	10^{-6}	IMS Signalling
6	Non-GBR	6	300 ms	10^{-6}	Video (buffered streaming) TCP-based (e.g., www, e-mail, chat, ftp, p2p file sharing, progressive video, etc.)
7		7	100 ms	10^{-3}	Voice, Video (live streaming) Interactive Gaming
8		8	300 ms	10^{-6}	Video (buffered streaming)
9*		9			TCP-based (e.g., www, e-mail, chat, ftp, p2p file sharing, progressive video, etc.)


Guaranteed
(minimum)
Bit Rate

No
Guarantees

* QCI value typically used for the default bearer

EPC: Mobility Management

- X2 interface used when moving within a RAN coordinated under the same Memory Management Entity (MME)
- S1 interface used to move to another MME
- *Hard handovers* are used: A UE is connected to only one eNodeB at a time



Peter A. Steenkiste, CMU

14

EPC: Inter-cell Interference Coordination (ICIC)

- Reduces interference when the same frequency is used in a neighboring cell
- Goal is universal frequency reuse
 - » $N = 1$ in “Cellular principles” lecture
 - » Must avoid interference when mobile devices are near each other at cell edges
 - » Interference randomization, cancellation, coordination, and avoidance are used
- eNodeBs send *indicators*
 - » Relative Narrowband Transmit Power, High Interference, and Overload indicators
- Later releases of LTE have improved interference control
 - » “Cloud RAN”

Peter A. Steenkiste, CMU


15

Overview

- Motivation
- Architecture
- Resource management
- LTE protocols
- Radio access network
 - » OFDM refresher
- LTE advanced

Some slides based on material from
 “Wireless Communication Networks and Systems”
 © 2016 Pearson Higher Education, Inc.

Protocol Layers End-to-End



Overview

- Motivation
- Architecture
- Resource management
- LTE protocols
- Radio access network
 - » OFDM refresher
- LTE advanced

Some slides based on material from
“Wireless Communication Networks and Systems”
© 2016 Pearson Higher Education, Inc.

Peter A. Steenkiste, CMU

20

LTE Radio Access Network

- LTE uses OFDM and MIMO
- OFDM offers benefits similar to those of CDMA
 - » Good immunity to fading as only a small portion of the energy for any one link is typically lost due to a fade
 - » Fast power control to keep the noise floor as low as possible
- Additional advantages
 - » Highly resistant to fading and inter-symbol interference
 - » Low modulation rates on each of the many sub-carriers
 - » Sophisticated error correction
 - » Scales rates easier than CDMA
 - » Allows more advanced antenna technologies, like MIMO
- Breaks information into pieces and assigns each one to a specific set of sub-carriers

Peter A. Steenkiste, CMU


21

Different Solution for Up and Downlink

- **The downlink uses OFDM with Multiple Access (OFDMA)**
 - » Multiplexes multiple mobiles on the same subcarrier
 - » Improved flexibility in bandwidth management, e.g., multiple low bandwidth users can share subcarriers
 - » Enables per-user frequency hopping to mitigate effects of narrowband fading
- **The uplink uses Single Carrier OFDM (SC-OFDM)**
 - » OFDM but using a single carrier
 - » Provides better energy and cost efficiency for battery-operated mobiles
 - » Large number of subcarriers leads to high peak-to-average Power ratio (PAPR), which is inefficient

Peter A. Steenkiste, CMU


22



23

Resource Blocks

- A time-frequency grid is used to illustrate allocation of physical resources
- Each column is 6 or 7 OFDM symbols per slot
- Each row corresponds to a subcarrier of 15 kHz
 - » Some subcarriers are used for guard bands
 - » 10% of bandwidth is used for guard bands for channel bandwidths of 3 MHz and above



Peter A. Steenkiste, CMU

25

Overview

- Motivation
- Architecture
- Resource management
- LTE protocols
- Radio access network
 - » OFDM refresher
- LTE advanced

Some slides based on material from
 “Wireless Communication Networks and Systems”
 © 2016 Pearson Higher Education, Inc.

Peter A. Steenkiste, CMU

27

LTE-Advanced


- Carrier aggregation – up to 100 MHz
- MIMO enhancements to support higher dimensional MIMO – up to 8 x 8
- Relay nodes
- Heterogeneous networks involving small cells such as femtocells, picocells, and relays
- Cooperative multipoint transmission and enhanced intercell interference coordination
- Voice over LTE

Comparison LTE and LTE-Advanced

System Performance		LTE	LTE-Advanced
Peak rate	Downlink	100 Mbps @20 MHz	1 Gbps @100 MHz
	Uplink	50 Mbps @20 MHz	500 Mbps @100 MHz
Control plane delay	Idle to connected	<100 ms	< 50 ms
	Dormant to active	<50 ms	< 10 ms
User plane delay		< 5ms	Lower than LTE
Spectral efficiency (peak)	Downlink	5 bps/Hz @2x2	30 bps/Hz @8x8
	Uplink	2.5 bps/Hz @1x2	15 bps/Hz @4x4
Mobility		Up to 350 km/h	Up to 350–500 km/h

Relaying

- **Relay nodes (RNs) extend the coverage area of an eNodeB**
 - » Receive, demodulate and decode the data from a UE
 - » Apply error correction as needed
 - » Transmit a new signal to the base station
- **An RN functions as a new base station with smaller cell radius**
- **RNs can use out-of-band or inband frequencies**



Heterogeneous networks

- **It is increasingly difficult to meet data transmission demands in densely populated areas**
- **Small cells provide low-powered access nodes**
 - » Operate in licensed or unlicensed spectrum
 - » Range of 10 m to several hundred meters indoors or outdoors
 - » Best for low speed or stationary users
- **Macro cells provide typical cellular coverage**
 - » Range of several kilometers
 - » Best for highly mobile users

Heterogeneous networks

- **Femtocell**
 - » Low-power, short-range self-contained base station
 - » In residential homes, easily deployed and use the home's broadband for backhaul
 - » Also in enterprise or metropolitan locations
- **Network densification** is the process of using small cells
 - » Issues: Handovers, frequency reuse, QoS, security
- A network of large and small cells is called a **heterogeneous network (HetNet)**

